

Instruction Manual

FELDO Classic Line 1-4



General Features and Components

Selfwinding Automatic
Miyota clock mechanism of 21 rubies
Watch Diameter 45 mm
Case body – Stainless steel case shiny polished
Scratch-resistant cambered sapphire crystal glass
Water-Resistance – To 50 m (5 bar).



How to read the time:

The watch indicates the actual time via two clock hands and one window. This window is located on a rotating metal disc. The picture on the left shows this window. The hour clock numbers is attached to a disc under the rotating metal disc. Actually it is located close to three o'clock.

The big hand shows the minutes (actually ~50 minutes). The other one shows the seconds. So the actual time is 3 hour and 50 minutes.

Positions



1

1 Pull out the crown (one “click” out).



2

2 Rotate the crown clockwise until the actual time is set. Push back the crown.

Stopped Automatic Watch

If the watch is not worn, it will wind down and stop. We suggest the following procedure to start an automatic watch which has stopped. With the crown in Position 1, wind the crown clockwise for approximately 5 times, and the watch will start. Now wear the watch at the arm to do the final winding through your body's movements.

Caring for Your Watch

Even though your watch is water-resistant to 50 m, it is not recommended that you wear it in a hot shower, sauna or hot tub. For cleaning, please wipe the watch with the thin cloth (included to the shipment). Prevent the watch from heavy vibrations. We suggest sending your watch to the seller or to a watchmaker for maintenance or deep cleanup every 4 years.

Note:

To set the clock you have to rotate the crown clockwise.

**LUXURY PRODUCTS MADE
SALES HEADQUARTER**

**FELDO LUXURY S.L.
CALLE CRUZ No. 22
02500 Tobarra
ESPAÑA**

www.feldo-luxury.com